

BEABA – HOW TO REMATCH BABY CALL HD

Products have already been Matched (paired) in the production and users do not need to perform any matching procedure in the normal case. Follow these steps to re-match if needed :



Step 1 : Plug to 230 volts the parent unit (with LCD display) without the base unit.



Press and hold the ON/OFF button on the parent unit.



Step 2 : The baby unit must not be plugged to 230V. Then, press and hold the ON/OFF button on the baby unit. Still holding the On/Off button, plug it to 230V.



The blue led (11) starts flashing.



In less than 30 seconds, go to step 3.

Step 3 : On the parent unit, press and hold the « light button » (1) until « CO » appears on the display. Then, Press immediately and briefly (1 impulse) the « light button ».



The Parent Unit emits 2 BEEP tones to indicate the matching is successful and “_ _” will appear on the LCD.

Important: If « CO » is still flashing, press briefly (1 impulse) the « light button »



Important: “_ _” is on the display: the matching is finished.

Étape 4: On the baby unit, press « on/off button », the blue led (11) stop flashing.



*The temperature must appear on the baby unit.
Re-matching is OK.*